

Skylight Strip

Quote/Order Form

| | | |
|----------------------|------------|----------------------|
| Date: / / | Order No.: | Job Name: |
| Company Name: | | ABN: |
| Order Contact Name: | | Order Contact Phone: |
| Order Contact Email: | | Date order required: |
| Invoice Address: | State: | Post Code: |
| Delivery Address: | State: | Post Code: |
| Site Contact: | | Site Contact Phone: |

1. Quote / Order

Quote:

Order:

1. Skylight Kit Combinations (Includes materials to install 1 x skylight per kit)

| Type | Details | Qty. | Cut to Length (please specify length required) |
|-----------------------------------|---|------|--|
| Spacemaker/Versalink 1000: 4m Kit | Top Fibreglass Strip Twinwall Bottom Diffuser Strip 2 x 4000mm T-Bars Foam Infill Pair Stormtite Stitching Screws Rivets Twinwall Sealer Tape | | |
| Spacemaker/Versalink 1000: 6m Kit | Top Fibreglass Strip Twinwall Bottom Diffuser Strip 2 x 6000mm T-Bars Foam Infill Pair Stormtite Stitching Screws Rivets Twinwall Sealer Tape | | |
| Spacemaker/Versalink 1000: 8m Kit | Top Fibreglass Strip Twinwall Bottom Diffuser Strip 4 x 4000mm T-Bars Foam Infill Pair Stormtite Stitching Screws Rivets Twinwall Sealer Tape | | |
| Corrolink 1000: 4m Kit | Top Fibreglass Strip Twinwall Bottom Diffuser Strip 2 x 4000mm T-Bars Foam Infill Strip Stormtite Stitching Screws Rivets Twinwall Sealer Tape | | |
| Corrolink 1000: 6m Kit | Top Fibreglass Strip Twinwall Bottom Diffuser Strip 2 x 6000mm T-Bars Foam Infill Strip Stormtite Stitching Screws Rivets Twinwall Sealer Tape | | |
| Corrolink 1000: 8m Kit | Top Fibreglass Strip Twinwall Bottom Diffuser Strip 4 x 4000mm T-Bars Foam Infill Strip Stormtite Stitching Screws Rivets Twinwall Sealer Tape | | |

Alternatively, you can order items required individually below:

3. Fibreglass Top & Twinwall Bottom

| Type | Length | Qty. | Cut to Length (please specify length required) |
|---|--------|------|--|
| Spacemaker/ Versalink 1000 Top Fibreglass Strip | 4m* | | |
| | 6m* | | |
| | 8m* | | |
| Corrolink 1000 Top Fibreglass Strip | 4m* | | |
| | 6m* | | |
| | 8m* | | |
| Twinwall Diffuser Bottom Strip | 4m* | | |
| | 6m* | | |
| | 8m* | | |

*Please note: you will be purchasing full lengths. We will cut these to your required lengths and you will be provided with any offcuts.

4. Accessories

| Type | Qty. | Type | Qty. |
|--|----------|--|------|
| Spacemaker Foam Infill (Pair: Front & Back) | | Twinwall Sealer Tape (50m Roll) | |
| Versalink 1000 Foam Infill (Pair: Front & Back) | | Stitching Screws - 50 pack Surfmist Storm-Tite 25mm | |
| Corrolink 1000 Foam Infill (915mm Strip 1/Skylight) | | Silicone: Clear/White (Please Circle) | |
| Aluminium T-Bar White - 40 x 50mm | 4m 6m | Rivets, White - 100 pack 3.2mm dia x 9.5mm | |
| Spacemaker/Versalink 1000 Accessory Bag: Foam Infill Pair 35 x Stormtite Stitching Screws 60 x Rivets 1m Twinwall Sealer Tape | | | |
| Corrolink 1000 Accessory Bag: Foam Infill Strip 35 x Stormtite Stitching Screws 60 x Rivets 1m Twinwall Sealer Tape | | | |

What you need:

- Fibreglass profiled top strip (4m, 6m & 8m only) - cut to match overall top sheet length, if required
- Twin wall bottom diffuser ceiling strip (4m, 6m & 8m only) - cut to match ceiling length, if required
- T-bar aluminium extrusions (4m & 6m only) - require 2 x T-Bars per light strip, either side of bottom diffuser strip
- Twin wall seal tape - require 460mm for each Skylight
- Foam infills (Spacemaker = 2 piece set per skylight, Corrolink-S = 1 piece per skylight, cut to size onsite)
- Stormtite Screws - fixed through profile/crest at 600mm centres, along both sides of the fibreglass profiled top strip
- Blind Rivets - fixed through T-Bar at 300mm centres
- Silicone - run bead of silicone along top of horizontal section of T-Bar prior to pressing Twinwall into place and along Z Flashing prior to pressing foam infill into place

Please request and review engineering specifications prior to ordering skylights